

EXOS Function Codes and Error Codes

```

;*****
;
; This file defines EXOS variables, function codes, error codes and software
; interrupt codes as externals. It should be assembled to a .REL file and
; then linked with any code which uses EXOS. It produces no object code, just
; defines symbols.
;
err_code      defl      100h
;
err           MACRO     name
err_code      defl      err_code - 1
name          PUBLIC   name
name          equ       err_code
ENDM
;
;
var           MACRO     name,number
name          equ       number
name          PUBLIC   name
ENDM
;
;
-----
;
;                               EXOS FIXED VARIABLES
;                               =====
;
var           USR_P3,      0BFFFh ;Four segments which were in Z-80 space
var           USR_P2,      0BFFEh ; when EXOS was last called.
var           USR_P1,      0BFFDh
var           USR_P0,      0BFFCh
;
var           STACK_LIMIT, 0BFFAh ;Bottom limit of stack for devices.
;
var           RST_ADDR,    0BFF8h ;Warm reset address
;
var           ST_POINTER,  0BFF6h ;Address of status line RAM
var           LP_POINTER,  0BFF4h ;Address of start of video LPT.
;
var           PORTB5,      0BFF3h ;Current contents of Z-80 port 0B5h.
;
var           FLAG_SOFT_IRQ, 0BFF2h ;Flag <>0 to cause software interrupt.
;
;
-----

```

FUNCTION CODES

===== EXOS Function Codes and Error Codes =====

```

var @RESET, 0 ; Reset system
var @OPEN, 1 ; Open channel
var @CREAT, 2 ; Create channel
var @CLOSE, 3 ; Close channel
var @DEST, 4 ; Destroy channel
var @RDCH, 5 ; Read character
var @RDBLK, 6 ; Read block
var @WRCH, 7 ; Write character
var @WRBLK, 8 ; Write block
var @RSTAT, 9 ; Read status
var @SSTAT, 10 ; Set channel status
var @SFUNC, 11 ; Special vartion
var @EVAR, 16 ; Set/read/toggle EXOS variable
var @CAPT, 17 ; Capture channel
var @REDIR, 18 ; Re-direct channel
var @DDEV, 19 ; Set default device
var @SYSS, 20 ; Return system status
var @LINK, 21 ; Link device
var @READB, 22 ; Read EXOS boundary
var @SETB, 23 ; Set USER boundary
var @ALLOC, 24 ; Allocate segment
var @FREE, 25 ; Free segment
var @ROMS, 26 ; Locate ROMs
var @BUFF, 27 ; Allocate channel buffer
var @ERRMSG, 28 ; Return error message.

```

ERROR CODES
=====

General errors returned by the EXOS kernel

- err .IFUNC ;0FFh Invalid function code
- err .ILLFN ;0FEh EXOS function call not allowed
- err .INAME ;0FDh Invalid name string
- err .STACK ;0FCh Insufficient stack

- err .ICHAN ;0FBh Invalid channel number (0FFh) or channel
does not exist.
- err .NODEV ;0FAh Device does not exist (OPEN/CREATE)
- err .CHANX ;0F9h Channel already exists (OPEN/CREATE)
- err .NOBUF ;0F8h No ALLOCATE BUFFER call made (OPEN/CREATE)
- err .BADAL ;0F7h Bad ALLOCATE BUFFER params. (OPEN/CREATE)
- err .NORAM ;0F6h Insufficient RAM for buffer.
- err .NOVID ;0F5h Insufficient video RAM.

- err .NOSEG ;0F4h No free segments (ALLOCATE SEG)
- err .ISEG ;0F3h Invalid segment (FREE SEG, SET BOUNDARY)
- err .IBOUN ;0F2h Invalid user boundary (SET USER BOUND)
- err .IVAR ;0F1h Invalid EXOS variable number
- err .IDESC ;0F0h Invalid device descriptor type (LINK DEV)

General errors returned by various devices

- err .ISPEC ;0EFh Invalid special function code
- err .2NDCH ;0EEh Attempt to open second channel
- err .NOFN ;0EDh Function not supported
- err .ESC ;0ECh Invalid escape character
- err .STOP ;0EBh Stop key pressed

public .SWI

File related errors

- err .NOFIL ;0EAh File does not exist
- err .EXFIL ;0E9h File exists (CREATE)
- err .FOPEN ;0E8h File already open
- err .EOF ;0E7h End of file met in read
- err .FSIZE ;0E6h File is too big
- err .FPTR ;0E5h Invalid file pointer value.
- err .PROT ;0E4h Protection violation

```

; Keyboard errors
;
err .KFKEY ;0E3h Invalid function key number
err .KFSPC ;0E2h Run out of function key space
;
;
; Sound errors
;
err .SENV ;0E1h Envelope is too big or number 255.
err .SENBf ;0E0h Not enough room to define envelope
err .SENLO ;0DFh Envelope storage requested too small (ie. <2)
err .SQFUL ;0DEh Sound queue is full (and WAIT_SND <> 0)
;
;
; Video errors
;
err .VROW ;0DDh Invalid row number to scroll
err .VCURS ;0DCh Attempt to move cursor off page
err .VCOLR ;0DBh Invalid colour passed to INK or PAPER
;
err .VSIZE ;0DAh Invalid X or Y size to OPEN
err .VMODE ;0D9h Invalid video mode to OPEN
err .VDISP ;0D8h Naff parameter to DISPLAY
err .VDSP2 ;0D7h Not enough rows in page to DISPLAY
;
err .VBEAM ;0D6h Attempt to move beam off page
err .VLSTY ;0D5h Line style too big
err .VLMOD ;0D4h Line mode too big
err .VCHAR ;0D3h Can't display character on graphics page
;
;
; Serial errors
;
err .BAUD ;0D2h Invalid baud rate
;
;
; Editor errors
;
err .EVID ;0D1h Invalid video page for OPEN.
err .EKEY ;0D0h Trouble in communicating with keyboard.
err .ECURS ;0CFh Invalid co-ordinates for positioning cursor.
;
;
; Cassette errors
;
err .CCRC ;0CEh CRC error from cassette driver
;

```



```
;*****  
;  
;  
; SOFTWARE INTERRUPT CODES  
;=====  
;  
; var      ?FKEY,  10h      ;Function keys 10h...1Fh  
; var      ?STOP,  20h      ;Stop key  
; var      ?KEY,   21h      ;'any key' 21h  
;  
; var      ?NET,   30h      ;Network data received.  
;  
;  
;
```